



Data sheet

Bulk regen trolley 12 refrig./reg. 400V

The intelligent individual distribution system.



More Info

The Regiostation, the optimal transport, distribution and regeneration unit for ward supply as well as equipped for a variety of other uses. With the compartment combination of cooling and regeneration, a complete supply from breakfast to lunch to dinner is made possible. Flexible programming allows any number of warming/regenerating/cooling cycles to be stored, activated and played back fully automatically. Standard with integrated light/heat bridge & independent control.

All processes, error messages, warnings and interventions in the control system are logged. All HACCP-relevant temperatures in the cooling and regeneration compartments are documented in real time for up to five years. The serial USB interface enables both data imports and exports of temperature curves and error logs. The Regiostation can be individually expanded with a wide range of accessories, including a tray slide made of CNS round tubing, a fold-down shelf, a Formica panelling for the perfect look, or even a dispensing attachment.

TECHNICAL SPECIFICATIONS

Bulk regen trolley 12 refrig./reg. 400V



TECHNICAL SPECIFICATIONS

Material	stainless steel 1.4301
Dimensions	959,5 x 712 x 1460,5 mm
Worktop height	986 mm
Weight	155 kg
Connected load	7,1 kW
Rated voltage	3N AC 400 V 50/60 Hz
Plug type	CEE-Plug 400V/16A
Cable length	2500 mm
Refrigeration range	+2°C to +14°C
No. compartments	1
Refrigerant	Eisfink D2
Impact protection	4 corner bumpers
Castor type	Rustproof
Castor	2 fixed-; 2 swivel castors
Wheel diameter	160 mm

Order number **88 27 06 04**

BENEFITS

Stainless steel, high quality, hygienic.

Equipped with intelligent electronic control.

Customized 7-day programming based on meal plans, eliminating time-consuming daily adjustments or changes.

Ideally suited for ward supply and dining room.

Smooth CNS cover, heated with a warming zone, separately switchable and adjustable via the removable control on the top (with sneeze guard).

The compartment combination of a cooling compartment as well as the recirculating air regeneration compartment ensures a wide range of application possibilities.

Clean with a suitable agent for stainless steel, for example with a hot, mild detergent solution. Then rub the surface dry with a soft cloth.